

Kiuas PÄÄLLE paina kerran I/O painiketta.

ÄLÄ TEE MUUTA, JOS ET HALUA VAIHTAA ASETUKSIA. SAUNA ON VALMIS N. 30 MIN KULUTTUA.

Paina kerran nuolinäppäintä (SET) jos haluat **ajastaa kiukaan lämpiämään myöhemmin**.

Aika, jonka kuluttua sauna on valmis, valitaan +/- näppäimillä.

Paina toisen kerran nuolinäppäintä (SET) jos haluat **muuttaa kiukaan päällä oloaikaa**.

Päällä oloaika valitaan +/- näppäimillä.

Paina kolmannen kerran nuolinäppäintä (SET) jos haluat **muuttaa saunan lämpötilaa**.

Lämpötila valitaan +/- näppäimillä (suositus 60 astetta).

To turn ON heater, press the I/O button once.

DO NOT DO ANYTHING ELSE IF YOU DO NOT WANT TO CHANGE THE SETTINGS.

SAUNA IS READY AFTER 30 MIN.

Push arrow (SET) button once if you want sauna to be ready later (i.e. after 4h)

by pressing +/- buttons.

Push arrow (SET) button twice if you want to change time how long heater is ON

by pressing +/- buttons.

Push arrow (SET) button three times if you want to change sauna temperature

(recommended 60 degrees) by pressing +/- buttons.

