

FIREPLACE

- **Follow the instructions on the wall when using the fireplace.**
- **Fireplace switch (in the wall near the fireplace) affects the air ventilation which creates such a pressure inside the apartment that air is more easily removed through the chimney.**
- **Make sure that the cooker hood is closed (position OFF) and air ventilation position is 1.**
- **Opening a window or balcony door will help creating a good draft in the chimney.**
- **It's allowed to burn only 2 – 3 full loads in the fireplace per day (max. 2 loads at a time), appr. 15 – 20 kg of wood. Burn only dry wood.**
- **The draft may be weaker than usually during low pressure and rain.**
- **When the fireplace hasn't been used for a while, it's possible that there is an airlock in the chimney. Dry up the chimney by burning a piece of paper in the middle hatch of the fireplace. Draft is adequate when the chimney sucks up the ashes of the paper. After this, it's allowed to make the fire.**
- **Sudden heavy heating can damage the fireplace especially when the fireplace hasn't been used for a while.**
- **Place the wood vertically in back of the fireplace. Don't load the fireplace full of wood.**
- **When the fireplace is not in use, keep the chimney cover closed. Especially during low pressure and rain, when using a fireplace in an adjoining apartment, smoke can enter the apartment if the chimney cover is open.**
- **NOTE! DO NOT CLOSE CHIMNEY COVER TOO SOON AFTER USING FIREPLACE! CLOSE THE CHIMNEY COVER ONLY WHEN THE CARBONS ARE COMPLETELY BLACK.**

IF SMOKE COMES INTO THE APARTMENT:

- **Make sure that the chimney cover is open.**
- **Burn paper in the middle hatch of the fireplace.**
- **Open the apartment window or balcony door.**
- **There is a fire alarm in the apartment. Even a small amount of smoke can release the fire alarm. If you notice that the chimney doesn't work properly, start airing the apartment immediately!**