

DRYING CABINET

The apartments are equipped with drying cabinets, located just inside the entrance.

There are three rows of drying racks in the cabinet. The racks can be drawn out to make the hanging of the laundry easier. Hang the longer pieces of clothing on the sides and shorter on the middle racks. The centre of the cabinet needs to be left clear for the air to flow efficiently and thereby ensure that the clothes dry quickly and evenly.

There are two controls to adjust on the top panel (markings varies according to the model of the cabinet)

- Normal dry (energy saving): blue range or 0-I range
- Quick dry (fairly hot): the range of temperature in the grey are 40-60 C° or range I-II
- Maximum length is four hours. Time needed for drying depends on the amount of the laundry and thickness of the fabrics.
- Notice! The materials of shoes or other non-washable items may be damaged or create dangerous vapors with intense heat.

