

## INSTRUCTIONS FOR USING THE FIREPLACE

- Adjust the cooked hood power to position 1 (above the stove); otherwise the fireplace switch doesn't work.
- Push the fireplace switch (in the picture). It's located on the wall, behind the TV or in the hallway.
- Open the chimney cover(s).
- Open the air flow controls (grate) of the fireplace.
- Set the firewood vertically into the fire chamber. Leave some space between the firewood, so that the fire will get some air and burn properly. Don't load the fireplace full of wood.
- Add a handful of splinters of wood, some pieces of birch bark or crumpled newspaper to between the firewood. Then you can light the fire.
- When the fire has ignited and the chimney draws well, you can set the air controls (grate) to smaller or even close them. The powered fireplace ventilator will close by itself after it has been working about 20 minutes.
- As long as you want to keep the fire, add one or two firewood at a time into the fireplace.
- The draft may be weaker than usually during low pressure and rain.
- When the fireplace hasn't been used for a while, it's possible that there is an airlock in the chimney. Dry up the chimney by burning a piece of paper in the middle hatch of the fireplace. Draft is adequate when the chimney sucks up the ashes of the paper. After this, it's allowed to make the fire.
- Sudden heavy heating can damage the fireplace especially when the fireplace hasn't been used for a while.
- Do not close the chimney cover before you are sure that fire and embers has extinguished.
- However, keep in mind that you need to close the chimney cover when the fire is out, otherwise the temperature in the apartment falls due to open chimney cover.
- It would be nice, if you would fill up the firewood-rack afterwards. It's easier to light the fireplace when the firewood has been indoors a little while. You can find firewood storage right outside your apartment, next to the front door. The storage key is in the hall. Thank you!



### IF SMOKE COMES INTO THE APARTMENT:

- Make sure the chimney cover is open
- Make sure the hood above the stove is on at least I-position
- Make sure the fireplace switch is on
- Burn paper in the middle hatch of the fireplace
- Open the apartment window or balcony door
- There is a fire alarm in the apartment. Even a small amount of smoke can release the fire alarm. If you notice that the chimney doesn't work properly, start airing the apartment immediately!