


MICROWAVE OVEN ROSENLEW

Use


1. Turn the power selector to the desired power to select the microwave power.
2. Select the time by turning the time selector to the desired time. The oven starts working immediately. If you select a short time, 2 min or shorter, turn the time selector first to a higher time (eg 4 or 5) and then to the smaller time.
3. When the selected time has elapsed, a beep tone will sound and the oven will stop working.

100W /  : To defrost frozen meat, fish and ready meals.

400W: Heating and cooking larger amounts of food as well as foods that cannot be mixed, such as boxed foods.

550W: Rapid heating and cooking of food, e.g. fish and vegetables.

700W: Rapid heating of beverages and ready meals.



DO NOT PLACE METAL DISHES OR ALUMINUM FOIL IN THE MICROWAVE OVEN!